


HOOT Drip Controller



Auto dialer connector harness
Connect Orange to orange.....

5 Light Panel Connector Guide

(4) Sensor wires from probe.
Match color to controller panel

Solenoid connectors to connect to solenoid in headworks riser

Blower and Pump breakers

Power bar, blower and Pump connect to power source

Ground screw

Aeration back pressure hose attach to back of blower